



814 3 WAY ADJUSTABLE SHOCKS

The 814 3 way shock installation process is the exact same as the “Trail Series” installation process with the exception the 3 way shocks have a third adjustment (allen head) that controls the high speed compression dampening of the shock.

Follow the instructions for your specific model here on the website under installation instructions for the initial installation process for your 3 way shocks.

You will tune the shocks according to the Trail Series installation instructions for the compression (low speed) and rebound settings.

Turn the high speed dampening adjustment (allen screw) fully counterclockwise, this is the softest setting, the same as the low speed compression and rebound adjustments. Start with 8 - 10 clicks (clockwise) on the high speed adjustment.

The high speed compression adjustment controls the dampening rate (stiffness) of the shock at higher shaft speeds. For example if you are running at a higher rate of speed and the shock bottoms out when hitting an obstacle you will want to increase (clockwise) the high speed adjustment approx. 2 clicks at a time until the shock doesn't bottom out on impact with an obstacle at higher speeds.

Adjusting High speed dampening will affect Low speed dampening slightly so take into account running the high speed adjustment too low will require the low speed compression adjustment to be run too high slowing down the efficiency of the shock. For most “normal” trail applications the High speed adjustment will not be lower than approx. 6 clicks.